JUNE 1946 PARTS LIST No. 1-5300

KODABROMIDE PRINTER
TYPE III

Use the illustrations in the front section of this parts list to correctly identify the part to be ordered. To avoid error, give the complete part name and number as listed numerically in the rear section.



EASTMAN KODAK COMPANY • ROCHESTER 4, N. Y.

About Repairing

The services and special tools of a skilled mechanic will be required for intricate repair work on your Kodabromide Printer Type III. If satisfactory repair facilities are not available locally, send your equipment to the nearest factory repair shop.

Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7



Figure 8



Figure 9

Figure 10

Figure 11



Figure 12



Figure 13

JUNE 1946

FIG.	PART NUMBER	1	2	3	4	5	6	PART NAME	No. REQD.
9	18482							Rivet - Negative plate spring	2
3	48324							Lockwasher - Front light shield hinge screw	2
4	48324							Lockwasher - Cover latch stud	2
5	55748							Pad - Aperture platen	1
1	57115							Foot - Felt	4
3	58348							Screw - Front light shield hinge	2
2	68976							Socket - Lamp	1
10	68986							Lens - Condenser	2
1	71939							Screw - Base plate	3
4	79026							Nut - Cover latch stud	2
3	79026							Nut - Front light shield hinge screw	2
12	87811							Cover	1
2	84404							Mirror	1
9	84425							Stud - Negative mask	2
7	84426							Spring - Negative mask	2
7	84430							Washer - Negative mask	2
3	84433							Stud - Lens mount	4
3	84434							Spring - Lens mount stud	4
3	84435							Washer - Lens mount stud	4
11	84436							Lens - 53-mm, mounted	1
3	84437							Lens - 49-mm, mounted	1
4	84447							Spring - Cover return	1
5	84459							Pin - Lower platen hinge	1
5	84460							Spring - Lower platen hinge	1
12	84462							Handle - Cover	1
4	84469							Pin - Cover hinge	1
12	84471							Stud - Lower platen cam lever	1
4	84472							Resistor	1
6	84475							Stud - Film guide	2
7	84480							Screw - Negative mask stud	2
13	84482							Upper Platen and Hinge Assembly	1
5	84483							Lower Platen and Hinge Assembly	1
2	84485							Base Assembly	1
4	84488							Actuating Switch and Bracket Assembly	1
12	86765							Stud - Cover return spring, long	1
9	86768							Spring - Negative plate	1
11	86783							Latch - Cover	1
11	86784							Stud - Cover latch	2
3	89350							Switch	1
9	94748							Nut - Negative mask stud	2
2	94749							Lamp - 75w-115v, S-11 white, CC2 fil S.C. bayonet base (No. 111 Photo Enlarger Lamp)	1
6	95139							Shield - Light	1
6	95140							Shield - Light, left	1
6	95144							Spring - Hinge	1
6	95145							Pin - Hinge	1
6	95359							Front Light Shield and Hinge Assembly	1
2	96627							Mirror and Bracket Assembly	1
2	96628							Extension Cord and Wire Assembly	1
8	102362							Negative Mask Assembly	1
9	102363							Negative Plate Assembly	1

NOTE: Unidentified parts in the parts list may be obtained, but are not available for immediate delivery.

FIG. PART NUMBER 1 2 3 4 5 6 PART NAME No. REQD.

EASTMAN KODAK COMPANY
ROCHESTER 4, N. Y.

6-46-GL-C

PRINTED IN THE UNITED STATES OF AMERICA